

KIDYWOLF®

PLAY TO GROW




QUICK START GUIDE FOR **KIDYMETAL**

For a better user experience, please read the instructions carefully before using this product.


THE DEVICE

EN FOLD/UNFOLD HANDLE AND PAN
DE GRIFF UND SCHALE EINKLAPPEN/AUSKLAPPEN
DK FOLD/UDFOLD HÅNDTAG OG PAN
ES PLIEGUE/DESPLIEGUE EL MANGO Y LA BANDEJA
FR PLIER/DÉPLIER LA POIGNÉE ET LE DISQUE
IT PIEGARE/APRIRE LA MANIGLIA E LA PIASTRA
NL HANDGRIEP EN PAN INKLAPPEN/UITKLAPPEN
NO FOLD/UTFOLD HÅNDTAK OG PAN
PL ZŁOŻYĆ/ROZŁOŻYĆ UCHWYT I WYJĄC
PT DOBRE/DESDOBRE A ALÇA E A BANDEIRA
RO PLIATI/DESLIATI MÂNERUL ȘI TIGAIA
SE FÄLL/FÄLL UT HANDTAG OCH PAN
CN 折叠/展开手柄与托盘





USAGE INSTRUCTIONS

- EN DO NOT TILT (KEEP PARALLEL TO THE GROUND)
DE NICHT KIPPEN (PARALLEL ZUM BODEN HALTEN)
DK VIP IKKE (HOLD PARALLEL MED JORDEN)
ES NO INCLINE (MANTENGA PARALELO AL SUELO)
FR NE PAS INCLINER (MAINTENIR PARALLÈLE AU SOL)
IT NON INCLINARE (MANTENERE PARALELO AL SUOLO)
NL NIET KANTELEN (PARALLEL HOUDEN AAN DE GROND)
NO IKKE VIP (HOLDE PARALLELT MED BAKKEN)
PL NIE PRZECHYLAĆ (UTRZYMYWAĆ RÓWNOLICIE DO PODŁOŻA)
PT NÃO INCLINE (MANTENHA PARALELO AO CHÃO)
RO NU ÎNCLINAȚI (MENȚINEȚI PARALEL CU SOLUL)
SE VÄND INTE (HÅLL PARALLELT MED MARKEN)
CN 禁止倾斜 (保持与地面平行)



USAGE INSTRUCTIONS

EN USE AT 1 TO 5 CM ABOVE THE GROUND
DE 1 BIS 5 CM ÜBER DEM BODEN VERWENDEN
DK BRUG 1 TIL 5 CM OVER JORDEN
ES UTILICE A UNA ALTURA DE ENTRE 1 Y 5 CM POR ENCIMA DEL SUELO
FR UTILISER À 1 À 5 CM AU-DESSUS DU SOL
IT UTILIZZARE A 1-5 CM DAL SUOLO
NL GEBRUIKEN OP 1 TOT 5 CM BOVEN DE GROND
NO BRUK 1 TIL 5 CM OVER BAKKEN
PL UŻYWAĆ W ODLEGŁOŚCI 1-5 CM NAD PODŁOŻEM
PT USE A 1 A 5 CM ACIMA DO CHÃO
RO UTILIZAȚI LA 1-5 CM DEASUPRA SOLULUI
SE ANVÄND 1 TILL 5 CM ÖVER MARKEN
CN 距地面1至5厘米处操作



METAL DETECTOR FOR KIDS FEATURES

Name: KIDYMETAL	Battery: Inner Battery Li-Ion 3,7V 1000mAh 3,7Wh
25X LED Lamp	Accessory: USB-C cable
Material: ABS, Silicone and aluminium	Weight: 700g
Voltage: DC 5V	Dimensions: 750 X 180 X 93 mm (Folded)

PACKAGING

1 x Detector	1 x User's Manual	1 x USB C Cable
1 x Colored box packaging		


ELECTRICITY SUPPLY

Use always the furnished cable to power the KIDYMETAL (AC/DC adaptor not included). Please fully charge before using for the first time. This toy contains a non-replaceable battery. The manual must be retained since it contains important information. You should periodically check the wires, plugs, shell and other parts for damage. The transformer, power supply or battery charger used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts. In the event of damage, it shall not be used until the damage has been repaired. Misuse of transformer can cause electrical shock. Rechargeable batteries are only to be charged under adult supervision. Do not expose battery to high or low extreme temperatures during use, storage or transportation. Low air pressure at high altitude can affect battery performances. Replacement of a battery with an incorrect type can defeat a safeguard (for example, in the case of some lithium battery types). Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, can result in an explosion. Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas. A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this toy. The toy shall only be used with a transformer for toys or a power supply for toys. The transformer or power supply is not a toy.

Only 5V standard charging is supported. Do not use any high-voltage chargers marked with "Quick Charge" (PD, etc.).

This toy should only be connected to equipment bearing either of the following symbols:



WARRANTY AND SERVICE

WARRANTY

Please contact the Point of Sales where you bought the product

SERVICE

2-year warranty (from date of purchase) subject to proper use. Warranty does not cover parts other than KIDYMETAL itself. 6 month limited warranty is applied on the battery.

Keep out of the reach of children under 3 years.

Under these circumstances, warranty doesn't apply:

A. Artificial destruction, inappropriate use, or used for commercial purposes. B. Warranty expired. C. Failure to present the Warranty Card. D. Content of the Warranty card is inconsistent with the actual object. Or blurred and unrecognizable. E. Dirt and scratches on the product itself or accessories. F. Repaired and modified by the user, damaged by natural disaster or external force. G. Defects caused by misuse, negligent use or abuse of the items (bumps, accidents, improper handling, liquid spillage, drops, etc.). H. Damage caused by pressure, torsion, exposure to humidity, exposure to extreme temperatures, sudden changes in temperature, corrosion, oxidation and, in general, chemical products or substances that may alter the product. I. Product used with water, in the rain.

BATTERY INFORMATION

Rechargeable batteries are only to be charged under adult supervision.


You should periodically check the wires, plugs, shell and other parts for damage.

Found damage should discontinue the use until the repair is done.


Please fully charge before using for the first time

Charging time depends on the charging equipment.

The equipment cannot be used while charging.



USAGE INSTRUCTIONS



QUICKSTART POWER ON

Long press and release KIDYMETAL power switch

BATTERY STATUS LED INDICATOR

GREEN = Device ON

ORANGE= Charging

GREEN= Fully charged

RED= Low battery

Note: The unit should be turned off while charging the battery

Red light flashes five times = Battery is too low and it should be charged in time.

TYPE C CHARGING CONNECTOR


3.5MM EARPHONE JACK

once inserted, the external sound cuts off automatically

Note:

1. The device will automatically shut down during charging.
2. The detector performs an auto-calibration during power-on, indicated by the indicator LEDs illuminating sequentially from the outermost ring to the center. For optimal detection sensitivity, keep the search coil away from ground or metal objects during this process.
3. When multiple machines are working simultaneously, please keep a distance of more than 5 meters from each other.

SIGNAL STRENGTH



Level 1
WEAK

Level 2

Level 3

Level 4
STRONG

Four kinds of sounds, with frequencies from low to high

MULTILINGUAL INSTRUCTION DOWNLOAD



Download instruction manual in your language.
Téléchargez le manuel d'instructions dans votre langue.
Laden Sie die Bedienungsanleitung in Ihrer Sprache herunter.
Scarica il manuale di istruzioni nella tua lingua.
Descarga el manual de instrucciones en tu idioma.

Download de handleiding in uw taal.

WARNING	Not suitable for children under 36 months. Long cord. Strangulation hazard. Small parts. Choking hazard.
ACHTUNG!	Nicht geeignet für Kinder unter 36 Monaten. Lange Schnur. Strangulationsgefahr. Kleine Teile. Erstickungsgefahr.
ADVARSEL /WARNING	Ikke egnet til børn/barn under 36 måneder. Lang ledning/lång kabel. Fare/risk for kvælning/kvævningsfare. Små dele/delar. Fare/risk for kvælning/kvævnning/kvælningsfare.
ATENCIÓN!	No apto para niños menores de 36 meses. Cordón largo. Peligro de estrangulamiento. Trozcos pequeños. Peligro de asfixia.
ΠΡΟΣΟΧΗ!	Ακατάλληλο για παιδιά κάτω των 36 μηνών. Μακρύ καλώδιο. Κίνδυνος στραγγαλισμού. Μικρά κομμάτια. Κίνδυνος πνιγμού.
ATTENTION!	Ne convient pas à des enfants de moins de 36 mois. Câble long. Risque de strangulation. Petites pièces. Risque d'étouffement.
AVVERTENZA!	Non adatto a bambini di età inferiore a 36 mesi. Cavo lungo. Rischio di strangolamento. Contiene piccole parti. Rischio di soffocamento.
OPGELET!	Niet geschikt voor kinderen jonger dan 36 maanden. Lang snoer. Gevaar voor wurging. Kleine stukjes. Verstikkingsgevaar.
OSTRZEŻENIE	Nieodpowiednie dla dzieci w wieku poniżej 36 miesięcy. Długi przewód. Ryzyko uduszenia. Małe części. Ryzyko zadławienia.
AVISO	Não adequado para crianças com menos de 36 meses de idade. Cordão longo. Risco de estrangulamento. Peças pequenas. Risco de asfixia.
ATENȚIE!	Nu este potrivit pentru copii cu vârsta sub 36 de luni. Cablu lung. Pericol de strangulare. Bucăți mici. Pericol de sufocare.
احذر	غير مناسب للأطفال دون سن 36 شهرا. قطع صغيرة. خطر الاختناق. سلك طويل. خطر الاختناق.
경고!	36개월 미만의 어린이에게는 적합하지 않습니다. 긴 코드. 긴 코드. 목이 졸릴 위험이 있습니다. 작은 부품. 질식 위험.
警告	36ヶ月未満のお子様には適していません。 コードが長い。窒息の危険性あり。 部品が小さい。窒息の危険性。
警告	不适合36个月以下儿童。电源线较长。勒颈危险。 零件较小。窒息危险。



DECLARATION OF CONFORMITY

Download the Declaration of Conformity with the QR code here:



FR "Vous trouverez les déclarations de conformité DoC en ligne sur le lien suivant :
<https://kidywolf.com/certification-produit/>"

NL "U vindt de verklaringen van overeenstemming DoC online op de volgende link:
<https://kidywolf.com/nl/productcertificatie/>"

EN "You will find the declarations of conformity - DoC on line on the following link:
<https://kidywolf.com/en/product-certification/>"

DE Die Konformitätserklärungen - DoC finden Sie online unter folgendem Link:
<https://kidywolf.com/de/product-certification/>"



LIBRETTO - BOOKLET

PAP 22

RACCOLTA CARTA - PAPER COLLECTION

Verifica le disposizioni del tuo Comune
Riduci il volume dell'astuccio
Check the disposition of your community
Reduce the volume of the box



Cet appareil se recycle

À DÉPOSER
EN MAGASIN



OU

À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr
Privilegiez la réparation ou le don de votre appareil!

www.kidywolf.com

Designed in Belgium / Made in China
Imported by
Nespart SRL - Drève Richelle 161 H
1410 Waterloo - Belgium

